

Ph.: +39 (011) 4701510 or 4701511 or 4704541 Fax +39 (011) 4703910 – Email: info@reinol.it

# **TECHNICAL DATA SHEET**

## **ACRI INKS 17/742**

#### **TECHNICAL CHARACTERISTICS**

Acri 17/742 are pigmented water-based inks formulated both for valve action and filter markers.

They can write smoothly on all kind of surfaces, both porous and non-

porous.

Great covering and lightfastness.

Wide range of colors from catalogue and on requirement

Colour ref. No:	BLACK 17/742	WHITE 17/742	RED 17/742	YELLOW 17/742	DARK GREEN 17/742
Viscosity, cps (25 °C) Brookfield LV1 100rpm	10 ± 5	25 ± 5	15 ± 5	15 ± 5	25 ± 5
Surface Tension, dyne/cm2	30 ± 5	30 ± 5	30 ± 5	30 ± 5	30 ± 5
pH:	7 ± 1	8 ± 1	7 ± 1	7 ± 1	7 ± 1
Lightfastness (1-8)	8	8	6 ÷ 7	8	8
Colour ref. No:	PINK 17/742	ORANGE 17/742	LIGHT GREEN 17/742	BLUE 17/742	VIOLET 17/742
Viscosity, cps (25 °C) Brookfield LV2 100rpm	25 ± 5	25 ± 5	25 ± 5	15 ± 5	15 ± 5
Surface Tension, dyne/cm2	30 ± 5	30 ± 5	30 ± 5	30 ± 5	30 ± 5
pH:	7 ± 1	7 ± 1	7 ± 1	7 ± 1	7 ± 1
Lightfastness (1-8)	6 ÷ 7	6 ÷ 7	7	8	7

#### **SUITABLE COMPONENTS**

Markers should ideally be stored horizontally and should be capped

firmly.

Nibs/Tips: High-porosity polyester nibs suitable for pigments

(porosity 60-65%)
Filters: 0,12-0,14 g/cm3

Inner Ball: Corrosion safe ball, both stainless steel or glass

Body: HDPE, Polypropylene

It is recommended to thoroughly test the components selected.

#### HANDLING INSTRUCTIONS

Store between 15°C and 35°C. Do not expose loose ink to temperatures higher than 35°C. Protect from frost and avoid direct

sunlight. Cleaning of all filling devices should be done immediately after finishing the process.

### **INSTRUCTION FOR USE**

Stir ink in the drums well before use for at least 15-20 min. Keep the inks under stirring while filling markers in order to avoid pigment sedimentation.

Drums should be closed tightly during storage.

#### **PACKING**

50 KG net Plastic Drums 200 KG net Plastic Drums

Any and all statements, information and recommendations contained in the present technical sheet are drawn up to the best of the experience and knowledge of Reinol and based on tests which we regard as reliable. Nevertheless this does not imply any responsibility, either implicit or explicit, on the side of Reinol. Buyers shall bear all risks arising from the use of the products, it is therefore understood that the sale of the product is not protected by any guarantee, either implicit or explicit.